



MicroNano
2023 International Conference




Toward selective detection of H₂S gas by AuNP-functionalized carbyne-enriched based sensors

L. A. Panes-Ruiz, L. Riemenschneider, B. Ibarlucea, G. Cuniberti

Chair of Materials Science and Nanotechnology

Carbon Allotropes

sp³ Hybridization




Diamond
Diamond like carbon (DLC)

- High thermal conductivity (2000 W/mK)
- High electrical resistivity (100 GΩ·m)
- High hardness (100 GPa)
- Elastic Modulus (1000 Gpa)
- Broad optical transparency


Rajak, D.K. et al. *Appl. Sci.*, **11**, 4445,(2021)

sp² Hybridization



0D Fullerene **1D** CNTs **2D** Graphene **3D** Graphite

Extensively studied and characterized



Zhou et al. *Nanoscale Research Letters*, **9:26** (2014)

sp Hybridization



Carbyne
Linear Carbon Chains (LCC)

Predicted in the 1960s:


- Stronger than diamond
- Extreme tensile stiffness
- Tunable mechanical properties
- Unstable

Unexplored
Experimental synthesis
and characterization

De Boer et al *J. Phys. Chem. C*, **125**, 15, 8268–8273 (2021)
Januszewski. A., et al. *Chem. Soc. Rev.* **43**, 3184-3203 (2014)


Carbon Allotropes

sp³ Hybridization




Diamond
Diamond like carbon (DLC)

sp² Hybridization



0D Fullerene **1D** CNTs **2D** Graphene **3D** Graphite


sp Hybridization



Carbyne
Linear Carbon Chains (LCC)

Electrical-based Gas Sensing Applications

Insulating properties



Panes-Ruiz, et al. *ACS Sens.* **3**, 79–86 (2018) Huang, et al. *Applied Physics Reviews* **10**, 021406 (2023)
Panes-Ruiz, et al. *Nano Res.* **15**, 2512-2521 (2022) Akinwande, D. et al, *Nature* **573**, 507–518 (2019).

?

Unexplored material for sensing applications


Non-invasive Diagnostics

Symptoms

- Abdominal discomfort
- Distention and bloating
- Diarrhea
- Constipation
- Brain fog
- Joint pain




Increase of Sulfate reducing bacteria (SRB)



Diagnostics Gold Standards

Small intestinal fluid aspiration (Biopsy)




Tissue is removed from the duodenum to make a culture for analysis

ADAM.

- ✗ Invasive
- ✗ High costs
- ✗ Inability to culture up to 70% of gut bacteria

Breath Test



- ✓ Non-Invasive
- ✓ Low costs
- ✓ Patient friendly


$H_2 < 20 \text{ ppm}$

$CH_4 < 10 \text{ ppm}$


$H_2S < 1 \text{ ppm}$

Gourab Dutta Banik et. al. *J. Breath Res.* **10** 026010, (2016)

Chemiresistors




Semiconducting Single-walled Carbon Nanotubes (sc-SWCNTs)




- High surface-to-volume ratio.
- Mechanical stability.
- Low limits of detection (ppb) at room temperature
- Low power consumption.


Multichannel Device



AuNP-SWCNTs



Panes-Ruiz, et al. *Nano Res.* **15**, 2512-2521 (2022)



Objectives


Can **Carbyne** be used as a sensor transducer for improved **H₂S** gas detection?

Tasks


1. Deposition and characterization of carbyne-enriched films.
2. AuNP functionalization.
3. Sensing performance towards low H₂S gas concentrations.

Multichannel Device Fabrication

Standard UV-Lithography and Metal Deposition



Polyimide (Kapton)




Localized film deposition
by metallic stencil



Carbyne-enriched Film Deposition

Ion-Assisted Pulse Plasma Deposition Method Company: *Swissimpianti Sagl*




Frequency: 5 Hz
Ar ion plasma: 2 kV & 100 mA
Pressure: 1.7×10^{-3} mbar


Effect of carbon plasma pulses
5000, 6000, 7000

Gas Sensor Characterization


5000 C pulses








6000 C pulses





7000 C pulses




- No film delamination at high carbon pulses.
- Increased film thickness (100 nm) and conductivity by increasing the number of carbon plasma pulses.
- High electrical conductivity, suitable for gas sensing experiments.
- Presence of **carbyne fraction** along with sp^2 carbon





R. Khanna. et al. *Scientific Reports*, 7,1, 1-8, (2017)



A. Piedade. et al. *Nanomaterials*, 10, 3-19 (2020)




Potentiostatic Electrodeposition of AuNP




V = -0.8 V t = 60 s	No funct
V = -0.4 V t = 60 s	V = -0.4 V t = 30 s

SEM Characterization




- Increased density of AuNP for higher voltages and longer deposition times.








Gas Chamber Setup

- 10 ppm H₂S gas bottle.
- Dry N₂ as carrier gas (Total flow rate = 500 sccm)
- Multiplexed electrical resistance measurement (64 channels).



H₂S Gas Exposure Experiments (500 ppb)

10 min H₂S & 15 min N₂



- Increased sensing response to **500 ppb** H₂S gas by increasing AuNP density.
- First gas exposure exhibited the highest sensitivity in all AuNP devices.
- No complete recovery after 15 min N₂ gas flushing suggests **chemisorption** of H₂S on AuNP.

- Successful fabrication of H₂S gas sensors based on carbyne-enriched films.
- **Localized** deposition using **5 Hz** and **5000** to **7000** carbon pulses.
- Deposited film is a **mixture** of sp and sp² carbon.
- **Higher** AuNP density by **increasing** voltage and deposition time.
- Increased sensing response to **500 ppb** H₂S gas by increasing AuNP density.
- **Chemisorption** of H₂S on AuNP.
- High number of sensors (64) allows:
 - Self-validation.
 - Resilience upon malfunction.
- Sensor recovery requires **improvement** (heating or UV light).
- Analysis in humid air and exhaled breath.


GEFÖRDERT VOM



Bundesministerium
für Bildung
und Forschung

CarbyneSense

ERA NET: 01DJ21006



Dr. Evangelos Gogolides

National Center for Scientific Research "Demokritos"
Greece

Prof. Dr. Levent Trabzon
Istanbul Technical University
Turkey

Prof. Dr. Mariya Aleksandrova
Technical University of Sofia
Bulgaria

Dr. Andrey Brigadin
Swissimpianti Sagl
Switzerland

Thank you for your attention !

Contact: luis_antonio.panes_ruiz@tu-dresden.de